




**G-MAR**<sup>®</sup>  
SPALINOVÉ VÝMĚNÍKY

# G-Air




**Výměníky  
Air Cross**



[www.g-mar.cz](http://www.g-mar.cz)

# Air Cross

## AIR CROSS




### Air Cross 21





AISI-316


\* = 900\* , 40



	*	*	Air-Cross	(mm)
0,500 MW	180 °C	95 °C	48 kW	286/455/1120
1 MW	180 °C	95 °C	97 kW	562/455/1120
3 MW	180 °C	95 °C	290 kW	600/920/1950
4 MW	180 °C	95 °C	387 kW	834/920/1950
6 MW	180 °C	95 °C	580 kW	1136/920/2385



AIRCROSS



- 
- 
- 
- 
- 

### Czech Republic

#### KARLOVY VARY

G-MAR PLUS, s.r.o.  
Majakovského 29  
360 05 Karlovy Vary  
Tel. +420 353 447 211 - 8  
Fax +420 353 540 163  
e-mail: g-mar@g-mar.cz

#### PRAHA

G-MAR PLUS, s.r.o.  
Ve stínu 19  
100 00 Praha 10 - Strašnice  
Tel. +420 274 776 014  
Fax +420 274 777 778  
e-mail: praha@g-mar.cz

#### BRNO

G-MAR PLUS, s.r.o.  
Francouzská 2  
618 00 Brno  
Tel. +420 548 212 195  
Fax +420 548 212 474  
e-mail: brno@g-mar.cz

#### OSTRAVA

G-MAR PLUS, s.r.o.  
Stodolní 12  
702 00 Ostrava 2  
Tel. +420 596 115 843  
Tel./fax +420 596 113 013  
e-mail: ostrava@g-mar.cz

### Slovakia

#### NITRA

G-MAR, s.r.o.  
Murgašova 2, SK - 949 01 Nitra  
Tel./fax +421 376 503 527  
e-mail: palenikova@g-mar.sk

### Russia

#### MOSKVA

Profsoyuznaya st. 78, suite 702  
117393 Moscow Russia  
Tel./fax +709 542 465 20  
e-mail: psv@g-mar.ru



[www.g-mar.cz](http://www.g-mar.cz)